


Installation requirements for Pas24/ SBD High
Security Windows

Date of Issue
09/02/09



- **T & H** = Standard toe and heel unit in sash to ensure correct operation
- **P** = Additional packers at all points of locking or adjacent to hardware.
- Frame must be firmly fixed to substrate as per *GGF Guide lines* i.e. fixing no more than 600mm apart and a min from corner of 150mm